

<u>R-100</u>	<u>T-101</u>	<u>MV-102</u>	<u>T-103</u>	<u>MV-104</u>	<u>P-105</u>	<u>P-106</u>	<u>BA-107</u>
STIRRED BOMB REACTOR	TANK FEED WATER	MANUAL SHUT-OFF VALVE	TANK TAR/HEAVY OIL	MANUAL SHUTOFF VALVE	PUMP	PUMP	BALL VALV SOL ACTUAT
<u>BA-115</u>	<u>MV-116</u>	<u>BA-117</u>	<u>HE-118</u>	<u>T-119</u>	<u>MV-120</u>	<u>MV-121</u>	<u>BA-122</u>
BALL VALVE SOL ACTUATED	MANUAL SHUTOFF VALVE	BALL VALVE SOL ACTUATED	HEAT EXCHANGER TUBE-IN-TUBE	TANK OIL ACCUM	MANUAL SHUTOFF VALVE	MANUAL SHUTOFF VALVE	BALL VALV SOL ACTUAT
<u>BA-126</u>	<u>R-200</u>	<u>MV-201</u>	<u>MV-202</u>	<u>MV-203</u>	<u>BA-204</u>	<u>T-205</u>	<u>MV-206</u>
BALL VALVE SOL ACTUATED	BOMB REACTOR	BALL VALVE SOL ACTUATED	MANUAL SHUTOFF VALVE	MANUAL SHUTOFF VALVE	BALL VALVE SOL ACTUATED	TANK HEATED SODIUM	MANUAL SHUTOFF VA SAMPLE PO





FIG. 2

<u>BA-108</u>	<u>MV-109</u>	<u>MV-110</u>	<u>BA-111</u>	<u>BA-112</u>	<u>V-113</u>	<u>P-114</u>
BALL VALVE SOL ACTUATED	MANUAL SHUTOFF VALVE	MANUAL SHUTOFF VALVE	BALL VALVE SOL ACTUATED	BALL VALVE SOL ACTUATED	SEPARATOR	PUMP
<u>BA-123</u>	<u>T-124</u>	<u>MV-125</u>	<u>BA-126</u>	<u>MV-127</u>	<u>BA-128</u>	<u>P-129</u>
BALL VALVE SOL ACTUATED	TANK GAS ACCUM	MANUAL SHUTOFF VALVE	BALL VALVE SOL ACTUATED	MANUAL SHUTOFF VALVE	BALL VALVE SOL ACTUATED	TANK OIL ACCUM
<u>MV-207</u>	<u>P-208</u>	<u>MV-209</u>	<u>BA-210</u>	<u>HE-211</u>	<u>MV-212</u>	<u>S-213</u>
MANUAL SHUTOFF VALVE	PUMP	MANUAL SHUTOFF VALVE	BALL VALVE SOL ACTIVATED	HEAT EXCHANGER TUBE-IN-TUBE	MANUAL SHUTOFF VALVE	SCRUBBER



REFERENCE DRAWING	NO.	BY	DATE	DESCRIPTION	APPROVAL	ENGINEER'S STAMP	APPROVAL STAMP	ON FORM DATE 10-29-02	DATE
							CHIEF CPHO-BRX-01-001	CHIEF CPHO-BRX-01-001	
							SCALE NONE	SCALE NONE	
							LOD NO. CPHO-BRX-01	LOD NO. CPHO-BRX-01	
							DRWNO ID CPHO-BRX-01-001	DRWNO ID CPHO-BRX-01-001	
							REV.	REV.	

BASKIS AND ASSOCIATES  
339 SOUTH CENTURY BLVD., RANTOUL, IL PHONE: 217-622-5000

HEAVY OILS PROCESSOR

PICTORIAL PROC FLOW DIAGR